



## TOE UP OR TOE DOWN

If you are hand soldering then toe down is usually requested. If you are oven or non-contact soldering then toe up is preferred. As you may know, the heel fillet gives most of the solder strength once the part is soldered and bonded to the PCB. Choosing the correct foot position will help you accomplish the strongest possible solder joint.